## HYDROREP ECO





**ECO-COMPATIBLE WATER-REPELLENT PROTECTION** 

UNPOLISHED STONE AND AGGLOMERATES. **CONCRETE. TERRACOTTA. EXPOSED BRICKS. OUARRY TILES. PLASTER. TUFF** 



### WHAT IT'S FOR

- · Water repellent with natural effect.
- Deeply penetrates the material while allowing the surface to breathe.
- Hampers the build-up of algae, moulds and lichen.
- Protects the surface against deterioration caused by weathering.

### ADVANTAGES

- · Anti-fouling barrier certified by tests conducted in conformity to the UNI EN ISO 846: 1999 method.
- · Ideal for protecting external walls.
- · Resists UV radiation.
- Does not alter terracotta frost resistance.
- · It protects against efflorescence.
- Can be applied to surfaces with residual humidity: drastically reduced application
- The treatment preserves the material's level of breathability above 90%.

# organic decay

Anti-fouling tested in accordance with the UNI EN ISO 846: I 999 standard.



## **COVERAGE**

#### **APPROXIMATE COVERAGE (1 litre):**

Terracotta, exposed brick walls, quarry tiles, stone, plaster

10/20 m<sup>2</sup>

Concrete

8-10 m<sup>2</sup>

"Coverage shown is for guidance purposes only and refers to single coats"

#### **Packaging**

1 litre: boxes of 12.

5 litres: boxes of 4.

WARNINGS

• Keep out of reach of children.

• Do not disperse into the environment after use.

• Outdoor flooring must be properly laid before being treated and must satisfy all the specific requirements, including: adequate sloping, properly executed expansion joints, perfect isolation from the underlying ground, proven compatibility with sub-zero temperatures. It does not protect marble and limestone

#### **TEMPERATURES**

Storage temperature: from 5° to 30° C.
This product must be applied to surfaces with temperature between 10°C and 30°C.

### HOW TO USE IT

No dilution required: ready to use.

**Application:** Make sure that the surface is dry and clean, then apply the product by impregnating the material until it is saturated, using a brush or other application method. Dab any excess product with a clean cloth before it dries (roughly 10-15 minutes). The surface can be walked on after 4 hours. The water-repellent effect starts after 24 hours.

FOR PROFESSIONAL USE ONLY: spray the product (airless system) on vertical surfaces until they are saturated and use appropriate PPE, as specified in the safety information sheet.

Carry out a patch test on a small surface area to check for any changes in colour. Avoid accumulations of unabsorbed product.

Do not apply the product outdoors if rain is forecast. Any stubborn product residues can also be removed when dry, by using FASEZERO diluted 1:10 and a white disc. Avoid applying on surfaces with condensate build-up and under direct sunlight. Does not protect against acidic aggression.



